

# R.E.D. STEAMERS



METHOD BREWERS  
MINDFUL BREWING

## *Steaming Guide*

Note:

The steamers handle may over heat when used on a gas stove.



- **Put water in the steamer (600 ml maximum, or just under the pressure release valve)**
- **Heat it up on an electric or gas stove top for approximately 8-12 minutes (Note: cannot be heated via induction)**
- **Once the pressure gauge hits 2 bars, it is ready for use. This is the *recommended pressure*. Going beyond that will be too strong for milk steaming. Reduce to medium low heat once it has reached 2 bars.**

### **CAUTION:**

**Never let the steamer run out of water (while heating). It is dangerous. The Safety Valve cannot handle it. Like any steamer, this will cause over-pressure and may cause it to explode.**

*For more questions or concerns, email  
[service@themethodbrewers.com](mailto:service@themethodbrewers.com)*